



K111 KCP

Asphalt Cold Patch

DRIVEWAY

SIMPLE APPLICATION DIRECTIONS

- 1. Preparation:** Clean area to be patched by sweeping and removing all dirt and debris, especially loose pavement.
- 2. Application:** Empty contents of container directly onto area to be patched and spread out with shovel, rake or other flat device. Level material about 1/4" high for every inch of patch depth to allow for compaction. If patch is more than 2" deep, apply and compact in equal layers.
- 3. Compaction:** Thoroughly compact with shovel-back, tamper or any heavy, flat object or by driving over back and forth carefully, without turning wheels.

ADDITIONAL INFORMATION

- * Do not patch over mud or clay. Solid base stone is best.
- * If patch is temporarily soft or tacky due to unusually hot weather, sweep dust from surrounding pavement on to patch. This material is usually trouble free, even under harsh conditions.
- * In extreme cold weather, material may be stiff, in which case, place container in heated area prior to use (do not use open flame).
- * Keep from freezing.
- * Coverage: 10lbs per 1 sq. ft. of area at 1" depth; 50kilos per sq. meter of area at 2.5cm depth.